

LED Site Light

User Guide

IMPORTANT: Read these instructions fully before using the light. Retain these instructions for future reference.

This light is a portable LED lighting unit for use around the home, site or workplace.

Use of an RCD: When using an electrical appliance (particularly outdoors), we recommend the use of a residual current device (RCD) such as the Faithfull Tools model, product code **FPP RCD** or a power circuit breaker, for enhanced protection.

General Safety Rules

- Do not look directly into the LED light or shine the light directly in the face of others.
- Do not allow children to use LED lights unless under the supervision of an adult.
- Always check that the voltage displayed on the nameplate is the same as the mains power source.
- Never use an electrical appliance in the rain, in wet areas or with wet hands. Using electrical appliance under these conditions greatly increases the possibility of an electric shock.
- Prior to operation, carefully inspect the light for abnormalities and damage.
- Any part that is damaged, including the casing, cable or plug, should be properly and safely repaired or replaced by a qualified electrician before the light is used.







Storage

Store the light in a clean and dry area.

Cleaning

All exterior surfaces of the light can be wiped clean with a soft cloth dampened with a soap and water solution.

Do not immerse or submerge any part of the light in water or any other solvent.

Never use solvents or cleaning agents containing petroleum (petrol, kerosene,oil), paint thinner, turpentine, alcohol, or ammonia. Harsh materials like these can damage surfaces.

Maintenance

LED bulbs should not wear out under normal conditions and do not need to be replaced.

All repairs should only be carried out by qualified service personnel.

Opening or visible attempts to open or repair a light may void any guarantee and/or cause damage to the product or personal injury.

One-Year Home Use Limited Guarantee

Faithfull guarantees this product to the original purchaser for a period of ONE YEAR against any defects in material or workmanship but shall not cover damage caused by misuse, abuse, alteration, or accident. This product is intended for domestic and trade use. In the case of products used for hire the guarantee period is restricted to three months.

E-mail: enquiries@faithfulltools.com